

# MEP3C PROGRAMMER

## EASY GUIDE



**A** Programmer is mounted to wall and front flap is normally in closed position.




**B** Front flap opens up to display more buttons.

## SETTING THE TIME

The time should be automatically set but if you need to change it:


- 1** Move the slider to **TIME/DATE** position.
- 2** The hour will flash, use **+/-** keys to adjust up and down.
- 3** Use **>>** button to move to minutes, date and summer/winter time.



## SETTING THE PROGRAMMER

To set the programmer follow these steps:

- 1 Move the slider to **HEATING** position.
- 2 Use the +/- buttons to move between the options (1) 7 day, (2) 5 to 2 day & (3) 24 hour.
- 3 Use the >> button to move to "time on setting", Zone 1 symbol will be on, use the +/- buttons to set the "on time".  
Use the >> button to move to "time off setting".  
Again use the +/- buttons to set "off time", use >> button to move to Zone 2 and repeat as per Zone 1.



THIS IS THE FIRST SCREEN THAT WILL APPEAR WHEN THE PROGRAMMER IS TURNED ON

## ADVANCE FUNCTION

The advance function is for a one-off event. To set, follow these steps:

- 1 Move the slider to **RUN** position.
- 2 Use >> button to move to Z1, Z2 & HW.
- 3 Press the **ADV** button, this will over-ride the times, it will automatically go off when the next time setting is reached. It can be manually turned off by repeating the steps above and pressing the **ADV** button again.



## BOOST FUNCTION

To set the boost function follow these steps:

- 1 Move the slider to **RUN** position.
- 2 Use >> button to move to Z1, Z2 & HW.
- 3 Press the **+HR** buttons;
  - 1 press will give one hour
  - 2 presses will give 2 hours
  - 3 presses will give the max 3 hours.Pressing it again will switch off the boost function.

